

show radius remote-circuit-id-format

Syntax show radius remote-circuit-id-format

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays the format of the PPPoE remote circuit ID value sent from a DSLAM and captured on the router.

If the PPPoE remote circuit ID value is configured to include any or all of the agent-circuit-id, agent-remote-id, and nas-identifier components, the display lists the components included and the order in which they appear.

If the PPPoE remote circuit ID value is configured to use the format for the **dsl-forum-1** keyword of the radius remote-circuit-id-format command, the display indicates that this format is in effect.

Mode Privileged Exec

Published: 2009-10-09