

show radius servers

Syntax	show radius [<i>serverType</i>] servers [<i>filter</i>]
Release Information	Command introduced before JUNOS Release 7.1.0. pre-authentication keyword added in JUNOS Release 8.1.0.
Description	Displays information about the RADIUS servers configured on the router.
Options	<ul style="list-style-type: none">■ <i>serverType</i>—One of the following RADIUS server types:<ul style="list-style-type: none">■ authentication—Displays authentication information only■ accounting—Displays accounting information only■ dynamic-request—Displays dynamic-request information only■ pre-authentication—Displays preauthentication information only■ <i>filter</i>—See Filtering show Commands
Mode	Privileged Exec
Related Topics	<ul style="list-style-type: none">■ Monitoring RADIUS Dynamic-Request Server Information

Published: 2009-10-09