

subscriber disconnect

Syntax [no] subscriber disconnect

Release Information Command introduced before JUNOS Release 7.1.0.

Description Enables the E Series router to receive RADIUS-initiated disconnect messages from the RADIUS server. The **no** version restores the default, in which support for RADIUS-initiated disconnect messages is disabled on the router.



NOTE: This command and the RADIUS dynamic-request server feature replace the **radius disconnect client** command, which has been deprecated and may be removed completely in a future release. The RADIUS Disconnect Configuration mode has also been deprecated.

Mode RADIUS Configuration

Published: 2009-10-09