

## baseline log

---

**Syntax** baseline log [ last-reset | *time* [ *utc* ] *month day year* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Sets a baseline for logging events. To use the current system time, do not enter any options. There is no **no** version.

- Options**
- last-reset—Causes the router to display log messages generated since the last time the router was reset
  - *time*—Time and date after which the router displays messages that are timestamped. To set the time, use the following syntax:  
  
*Hour:Minute[:Second]*—Current time in 24-hour format; seconds are optional
  - *utc*—Indicates that the time entered is UTC (GMT) time; if you do not include this keyword, the router considers the time entered to be local time
  - *month*—Name of the month in English
  - *day*—Number of the day in the range 1–31
  - *year*—Four-digit number of the year

**Mode** Privileged Exec

---

Published: 2009-10-09