

show control-plane policer

Syntax	show control-plane policer protocol <i>protocolValue</i>
Release Information	Command introduced in JUNOS Release 8.0.0.
Description	Displays control plane information for a specified protocol or for all protocols.
Options	■ <i>protocolValue</i> —Name of the protocol
Mode	Privileged Exec, User Exec
Related Topics	■ Monitoring Control Plane Policer Information

Published: 2009-10-08