

## show dhcp server

---

**Syntax** show dhcp server [ statistics [ delta ] ] [*filter* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays the IP address(es) and statistics of the configured DHCP server.

- Options**
- server—DHCP Proxy Client configuration
  - statistics—Displays statistics for the DHCP server or relay agent
  - delta—Displays baselined statistics
  - *filter*—See Filtering show Commands

**Mode** Privileged Exec

**Related Topics** ■ Monitoring DHCP Server and DHCP Relay Agent Statistics

---

Published: 2009-10-08