

## show ip dhcp-external statistics

---

<b>Syntax</b>	show ip dhcp-external statistics [ <i>delta</i> ] [ <i>filter</i> ]
<b>Release Information</b>	Command introduced before JUNOS Release 7.1.0.
<b>Description</b>	Displays statistics for the DHCP external server.
<b>Options</b>	<ul style="list-style-type: none"><li>■ <i>delta</i>—Displays baselined statistics</li><li>■ <i>filter</i>—See Filtering show Commands</li></ul>
<b>Mode</b>	Privileged Exec
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Monitoring DHCP External Server Statistics</li></ul>

---

Published: 2009-10-08