

show ip mirror interface

Syntax show ip mirror interface [vrf *vrfName*] [*interfaceType* *interfaceSpecifier*]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays information about the interface mirroring configuration of all interfaces, or for a specific interface on which mirroring is enabled.



NOTE: This command is deprecated and might be removed completely in a future release. The function provided by this command has been replaced by the **show secure policy-list** command.

- Options**
- *vrfName*—Name of the VRF
 - *interfaceType*—Interface type; see Interface Types and Specifiers
 - *interfaceSpecifier*—Particular interface; format varies according to interface type; see Interface Types and Specifiers

Mode Privileged Exec

Related Topics ■ Monitoring the Packet Mirroring Configuration of IP Interfaces

Published: 2009-10-08