

## show l2tp destination profile

---

**Syntax** show l2tp destination profile [ *profileName* ] [ *filter* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays destination profile configuration.

- Options**
- *profileName*—Name of a profile
  - *filter*—See Filtering show Commands

**Mode** Privileged Exec

---

Published: 2009-10-09