

show l2tp dial-out

Syntax show l2tp dial-out [[detail] [state *operState*] | summary] [*filter*]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays the chassis-wide configuration, operational state, and statistics for L2TP dial-out.

- Options**
- detail—Displays configuration, states, and statistics
 - *operState*—One of the following operational states:
 - inService
 - initIncomplete
 - restricted
 - summary—Displays aggregate counts for virtual routers, targets, and sessions in each of the possible operational and administrative states
 - *filter*—See Filtering show Commands

Mode Privileged Exec

Published: 2009-10-09