

## show l2tp received-disconnect-cause-summary

---

**Syntax** show l2tp received-disconnect-cause-summary [*filter* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays aggregate summary statistics for all information received by an LAC from an LNS about the cause of an L2TP session disconnection. The LAC receives this information from the LNS by means of a PPP Disconnect Cause Code attribute value pair (AVP) included in an L2TP Call-Disconnect-Notify (CDN) message.

**Options** ■ *filter*—See Filtering show Commands

**Mode** Privileged Exec

---

Published: 2009-10-09