

Configuring Statistic Profiles for QoS

To begin to configure a statistics profile, enter Statistics Profile Configuration mode.

- Issue the **statistics-profile** command from Global Configuration mode:

```
host1(config)#statistics-profile statpro-1  
host1(config-statistics-profile)#
```

The router supports up to 250 statistics profiles.

Related Topics

- [Configuring Rate Statistics](#)
- [Configuring Event Statistics](#)
- [Monitoring QoS Statistics for Rates and Events](#)
- [statistics-profile command](#)

