

Monitoring Shared Shaper Algorithm Variables

Purpose Display information about the user-configurable variables for controlling the simple shared shaper algorithm.

Action To display information about all variables:

```
host1#show qos-shared-shaper-control
      control name      control
      value            units
-----
maximum voql           400    milliseconds
reaction factor         75    percent
convergence factor      50    percent
minimum dynamic rate    0     percent
```

Meaning Table 1 on page 1 lists the **show qos shared-shaper** command output fields.

Table 1: show qos shared-shaper Output Fields

Field Name	Field Description
control name	Name of the simple shared shaper control
control value	Value of the simple shared shaper control; default values are displayed if none specified
units	Expressed units for the value of the simple shared shaper control

- Related Topics**
- Configuring Simple Shared Shaper Algorithm Variables
 - show qos-shared-shaper-control command

