

Monitoring the Connect-Info RADIUS Attribute

Purpose Display the format for the Connect-Info attribute.

Action To display the format for the Connect-Info attribute:

```
host1(config)#show radius connect-info-format  
l2tp-connect-speed-rx-when-equal
```

Related Topics ■ show radius connect-info-format command

