

## Monitoring the NAS-Port-ID RADIUS Attribute

---

**Purpose** Display whether the router includes or excludes the subinterface number or adapter in the interface description that the router passes to RADIUS for inclusion in the NAS-Port-Id attribute.

**Action** To display information about the interface description for the NAS-Port-ID:

```
host1#show aaa intf-desc-format  
exclude sub-interface  
include adapter
```

**Related Topics** ■ [show aaa intf-desc-format command](#)

