

## Monitoring with the SRC CLI and the C-Web Interface

---

You can use the **show** commands available with the SRC CLI to monitor the operation and configuration of your SRC environment.

The C-Web graphical user interface (GUI) allows you to monitor the operation and configuration of your SRC environment by using a Web browser with Hypertext Transfer Protocol (HTTP) or HTTP over Secure Sockets Layer (HTTPS) enabled.

