

## SRC CLI Commands to View Statistics About NIC Operations

You can view statistics for the NIC process and for various NIC components. Table 1 on page 1 lists the commands you use to view NIC statistics.

**Table 1: Commands to Display NIC Statistics**

Command	Output Displayed
show nic statistics	All NIC statistics. The output for this command includes the output for the other <code>show nic statistics</code> commands.
show nic statistics agen t	NIC statistics for agents.
show nic statistics hos t	NIC statistics for a NIC host.
show nic statistics proces s	NIC statistics for the NIC process.
show nic statistics resolver	NIC statistics for resolvers.
show nic statistics slot	All NIC statistics for a specified slot. The output for this command includes the output for the <code>show nic statistics agent</code> , <code>show nic statistics host</code> , <code>show nic statistics process</code> , and <code>show nic statistics resolver</code> commands.

