

Configuring SRC-ACP to Manage the Backbone Network

To configure SRC-ACP to manage the backbone network:

1. Configuring Network Interfaces in the Directory
2. (Optional) Configure an action congestion point.
3. Configure guaranteed bandwidths for services.
4. Assign network interfaces to services.
5. Create congestion points in the directory.
6. Assign interfaces to congestion points.

Related Topics ■ *SRC-PE Network Guide*

