

Modifying the Subscriber Configuration (C-Web Interface)

To locate the CMTS device associated with a subscriber, the JPS maps the subscriber IP address in a message to the CMTS IP address to which the message must be delivered. This mapping specifies the subscriber IP pools associated with CMTS devices.

The tasks to configure a CMTS device to which the JPS can connect and the pools of subscriber IP addresses that are managed by that CMTS device are:

1. Configuring Subscriber IP Pools as IP Address Ranges (C-Web Interface)
2. Configuring Subscriber IP Pools as IP Subnets (C-Web Interface)

