

Setting the Timeout and Number of Events for SAE Directory Eventing

To configure the directory eventing timeout and the number of simultaneous events that the SAE can receive from the directory:

1. Click **Configure**, expand **Shared > SAE > LDAP**, and then click **Directory Eventing**.

The Directory Eventing pane appears.

2. Click **Create**, enter information as described in the Help text in the main pane, and then click **Apply**.

Related Topics ■ For information about setting up SAE groups, see [Configuring an SAE Group](#).

