

Configuring PCMM Record-Keeping Server Plug-Ins (C-Web Interface)

To configure an RKS plug-in:

1. Click **Configure**, expand **Shared > SAE**, and then expand the SAE group for which you want to create RKS plug-ins,
2. In the side pane, expand **Configuration > Plug Ins**.
3. Expand the plug-in that you created for RKS, and then click **PCMM RKS**.
4. Click **Create**, enter information as described in the Help text in the main pane, and then click **Apply**.

Related Topics ■ Configuring an SAE Group

