

## Removing Login Registrations (C-Web Interface)

---

You can delete all login registrations, or you can delete a specific registration.

To remove login registrations:

1. Click **Monitor > SAE > Registered > Login**.

The Login pane appears.

2. Enter information as described in the Help text in the main pane, and click **OK**.

To remove login registrations:

1. Click **Manage > Clear > SAE > Registered > Login**.

The Login pane appears.

2. Enter information as described in the Help text in the main pane, and click **OK**.

