

## Configuring Logging Destinations for the SDX SNMP Agent

---

To configure logging destinations:

1. Click **Configure**, and expand **SNMP > Agent**.
2. From the Create new list, select **Logger**.
3. Enter a name for the new Logger in the dialog box, and click **OK**.
4. For file-based logging, from the side pane, expand **File**, enter information as described in the Help text in the main pane, and then click **Create**.
5. For syslog-based logging, expand **Syslog**, enter information as described in the Help text in the main pane, and then click **Create**.

