

Accessing the VTA Configuration

To configure the SRC-VTA, select Configuration in the VTA Configuration Manager navigation pane.



CAUTION: If you have previously loaded or imported a configuration, and you select Create and create a new configuration, the configuration that you loaded or imported will be overwritten by the new configuration when you commit or export the configuration.



VTA Configuration Manager

Configuration

▶	Home
▶	Dir Connection
▼	Configuration
▶	Create
▶	Edit
▶	Load
▶	Commit
▶	Import
▶	Export

Configuration

You have the following options:

- [Create](#) a VTA configuration
- [Edit](#) a VTA configuration
- [Load](#) a VTA configuration from the directory
- [Commit](#) a VTA configuration to the directory
- [Import](#) a VTA configuration from a local file
- [Export](#) a VTA configuration to a local file

Juniper yourNet

From this screen you can perform the following tasks:

- Configuring the SRC-VTA to Manage Database Accounts
- Setting Up the SRC-VTA to Send E-Mail Notifications
- Configuring the SAE Proxy Processor
- Configuring the SRC-VTA to Run Scripts
- Configuring Events
- Configuring Event Handlers
- Configuring Identifiers for Subscribers and Sessions
- Using One VTA Account for Multiple Subscriber Sessions
- Logging Event Messages for the SRC-VTA
- Validating VTA Configurations
- Committing a VTA Configuration to a Directory

