

Logging Events Messages to a System Logging Server

To configure the SRC-VTA to save event messages on a system logging server:

1. In the VTA Configuration Manager navigation pane, select **Edit**.
2. Under Current Configuration, select **Logging**.

The current logging configuration appears.

3. To add a system log configuration, enter a name for the configuration in the New Syslog box, and click **Create**.

The Syslog configuration screen appears.

Current Configuration

Event Handlers	Actions	Processors	Logging	Subscriber ID and Lookup
Syslog				
syslog-1				
Name	Value			
Filter	<input type="text" value="/error-"/> <input type="button" value="Enable"/>			
Syslog Host	<input type="text" value="loghost"/>			
Syslog Facility	<input type="text"/> <input type="button" value="Disable"/> ?			
<input type="button" value="Save"/>				
syslog-2	<input type="button" value="Delete"/> ? <input type="button" value="Disable"/> ?			
New Syslog	<input type="text"/>			
<input type="button" value="Create"/>				

4. Edit the fields.

See System Logging Fields .

5. If you are finished configuring the SRC-VTA, save the configuration to a directory or local file.

See Committing a VTA Configuration to a Directory.

