

Copying Initialization Scripts to the C-series Controller

If you use a script that is not provided with the SRC software, you need to use the `file copy` command to copy your script to the C-series Controller. For example:

```
user@host> file copy ftp://user@myserver/routerinit.py /opt/UMC/sae/lib
Password:
```

