

Viewing Information About Subscriber Sessions in the Edge Network (C-Web Interface)

Purpose View information about subscriber sessions in the edge network with the C-Web interface.

Action To view information about subscriber sessions:

1. Click **ACP > Edge > Subscriber**.

The Edge/Subscriber pane appears.

The screenshot shows the Juniper C-Web interface. At the top, there is a navigation bar with tabs: Monitor, Configure, Diagnose, and Manage. The 'Configure' tab is active. On the right side of the navigation bar, it says 'Logged in as: admin' and has links for Refresh, Preferences, About, and Logout. On the left side, there is a sidebar menu with the following items: ACP (selected), CLI, Component, Date, Disk, Interfaces..., Iptables..., JPS, NIC, NTP, Redirect Server, Route..., SAE, Security, and System. The main content area is titled 'ACP' and 'Edge / Subscriber'. It contains four input fields with their respective descriptions and default values: 'Session Id' (text box), 'Slot' (text box), 'Style' (dropdown menu), and 'Virtual Router Name' (text box). Below these fields are 'OK' and 'Reset' buttons. The footer of the interface shows the copyright notice: 'Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy.' and the Juniper logo with the tagline 'Juniper Your Net.'

Field	Description	Default Value
Session Id	Subscriber session ID for which you want to list all matching subscriber sessions. Value: All or part of the subscriber session ID.	No value
Slot	Number of the slot for which you want to configure values. Value: Currently, the chassis has only one slot. The valid value is 0.	0
Style	Output style. Choices: brief: Minimal information	detail
Virtual Router Name	Name of virtual router from which to list subscriber sessions. Value: Virtual router name	No value

2. In the Session ID box, enter a full or partial session ID name to display information about one or more specific sessions, or leave this field empty to display information about all sessions.
3. In the Slot box, enter the number of the slot for which you want to display subscriber session information.
4. Select an output style from the Style list.
5. In the Virtual Router Name box, enter a virtual router name to display information about a specific virtual router, or leave the box empty to display information about all virtual routers.
6. Click **OK**.

The Edge/Subscriber pane displays a list of current subscriber sessions.

