

Viewing JPS Message Handler Statistics with the C-Web Interface

Purpose View information about the JPS message handler.

Action Click **JPS > Statistics > Message Handler**.

The Statistics/Message Handler pane displays the JPS message handler statistics.

Monitor

Configure

Diagnose

Manage

Logged in as: admin

Refresh

Preferences

About

Logout

CLI

Component

Date

Disk

Interfaces...

JPS

NIC

NTP

Redirect Server

Route...

SAE

Security

System

JPS

Statistics / Message Handler

JPS Message Handler

Messages received	0
Message handled	0
Message dropped	0
Average non-decoding time in JPS (last 5000 messages, ms)	0
Throughput (last 60s, msgs/s)	0

Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. [Trademark Notice](#). [Privacy](#).

Juniper your Net.

Related Topics ■ Overview of the JPS

