

## Viewing Agents

**Purpose** View information about an agent.

**Action** 1. Click **Monitor > NIC > Data > Agent**.

The Data/Agent pane appears.

The screenshot shows the Juniper Networks configuration interface. The top navigation bar includes 'Monitor', 'Configure', 'Diagnose', and 'Manage'. The 'Monitor' tab is selected, and the left sidebar shows a tree view with 'NIC' highlighted. The main content area is titled 'Data / Agent' and contains three input fields: 'Maximum Results' (a text box), 'Name' (a text box), and 'Slot' (a text box with the value '0'). Below these fields are 'OK' and 'Reset' buttons. The bottom of the interface shows the copyright notice 'Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy.' and the Juniper logo.

2. In the Maximum Results box, enter the maximum number of results that you want to receive.
3. In the Name box, enter the name of the agent for which you want to view data.
4. In the Slot box, enter the number of the slot for which you want to display agent data.
5. Click **OK**.

The Data/Agent pane displays the properties for the agent.

