

Viewing Statistics for a NIC Host

Purpose View statistics for a NIC host.

Action user@host> **show nic statistics host**

Component Statistics
Component Name /hosts
Number of Components Restart 0
Number of No Match Resolutions 0
Number of Resolution Errors 0
Number of Resolutions 0

Meaning Table 1 on page 1 describes the output fields for the **show nic statistics host** command. Output fields are listed in the order in which they appear.

Table 1: Output Fields for show nic statistics test

Field Name	Field Description
Component name	Name of component—/hosts indicates NIC host. A specific host has the format /hosts/ <i>hostname</i> .
Number of Components Restart	Number of NIC resolvers and agents that have restarted in the host.
Number of No Match Resolutions	Number of resolution requests that did not return data.
Number of Resolution Errors	Number of errors encountered when processing resolutions requests.
Number of Resolutions	Number of successful data resolutions; for example, the SAE reference for a specified IP address, the login name for a specified IP address, or the SAE reference for a specified login name.

