


## Viewing NTP Peers (C-Web Interface)

**Purpose** View a list of NTP peers.

**Action** 1. Click **Monitor > NTP > Associations**.

The Associations pane appears.



2. To suppress symbolic addressing, select the **No Resolve** box.
3. Click **OK**.

The Associations pane displays the list of NTP peers.

