

## Viewing Statistics for Specific JUNOS Device Drivers (C-Web Interface)

**Purpose** View SNMP statistics about devices.

**Action** 1. Select **SAE** from the side pane, click **Statistics**, and then click **Device**.

The Device pane appears.

The screenshot shows the Juniper C-Web Interface. On the left is a navigation pane with a tree structure. The 'SAE' item is selected and highlighted in orange. The main content area is titled 'SAE' and 'Device'. It contains a form with two input fields: 'Device Name' and 'Style'. The 'Device Name' field has a text input box. The 'Style' field has a dropdown menu. Below these fields are 'OK' and 'Reset' buttons. To the right of the form, there is a help text area that reads: 'Name of a device. Please enter: All or part of the device name. For JUNOS router drivers and PCMM drivers, use the format default@routerName. Output style Choices: brief: Display only device names'. At the top right of the interface, there are links for 'About', 'Refresh', and 'Logout', and a status bar indicating 'Logged in as: admin'. The bottom of the interface shows the copyright notice 'Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy.' and the Juniper logo 'Juniper your Net.'

2. In the Device Name box, enter a full or partial device name for which you want to display information, or leave the box blank to display all devices.
3. Select an output style from the Style list.
4. Click **OK**.

The Device pane displays statistics for all devices.

