

Viewing Equipment Registrations

Purpose You can view all equipment registrations, or you can view a specific registration.

Action To view information about equipment registrations.

1. Click **Monitor > SAE > Registered > Equipment**.

The Registered/Equipment pane appears.

The screenshot shows the Juniper SAE configuration interface. On the left is a navigation menu with options: ACP, CLI, Component, Date, Disk, Interfaces..., Iptables..., JPS, NIC, NTP, Redirect Server, Route..., SAE (highlighted), Security, and System. The main area is titled 'SAE Registered / Equipment'. It contains four configuration fields: 'Mac Address' (a text box), 'Maximum Results' (a text box), 'Slot' (a text box), and 'Style' (a dropdown menu). To the right of these fields are help text boxes: 'Mac Address' explains the format and default; 'Maximum Results' shows the legal range and default; 'Slot' explains the chassis slot and valid values; 'Style' lists choices and the default. At the bottom of the configuration area are 'OK' and 'Reset' buttons. The footer of the interface includes copyright information for Juniper Networks, Inc. and the slogan 'Juniper Your Net.'

2. In the MAC Address box, enter a MAC address that specifies the equipment registrations that you want to display.

Use the format:

XX:XX:XX:XX:XX:XX

3. In the Maximum Results box, enter the maximum number of results that you want to receive.
4. In the Slot box, enter the number of the slot for which you want to display equipment registration information.
5. Select an output style from the Style list.
6. Click **OK**.

The Registered/Equipment pane displays information about the equipment registrations.

Related Topics ■ For information about login and equipment registrations, see the *SRC-PE Sample Applications Guide*.

