

Displaying IMS Status

Purpose Display IMS status.

Action `user@host> show component`

The system responds with a status message.

- Related Topics**
- Configuring the IMS Software
 - Monitoring IMS with the SRC CLI
 - Stopping the IMS Process

