

Viewing Information About Subscribers by IP Address

Purpose View information about subscriber sessions by IP address.

Action 1. Click **Monitor > SAE > Subscribers > IP**.

The Subscribers/IP pane appears.

Field	Description	Default
IP Address	IP address of subscriber sessions. <i>Value:</i> All or part of the subscriber IP address	No value
Maximum Results	Number of results to be displayed. <i>Legal range:</i> 1..INF	25
Secret	Display subscriber sessions and service sessions for hidden services.	Disabled
Slot	Display SAE information for a specified slot. <i>Value:</i> Currently the chassis has only one slot. The valid value is 0.	0
Style	Output style <i>Choices:</i> brief: Display only subscriber sessions terse: Display subscriber session ID, login name, and IP address	Detail

2. In the IP Address box, enter a full or partial IP address for which you want to display information, or leave the box blank to display all subscriber sessions.
3. In the Maximum Results box, enter the maximum number of results that you want to receive.
4. Select the **Secret** check box to set a flag indicating that subscriptions and service sessions from hidden services are displayed.
5. In the Slot box, enter the number of the slot for which you want to display subscriber session information.
6. Select an output style from the Style list.
7. Click **OK**.

The Subscribers/IP pane displays information about subscriber sessions.

