

Overview of SRC User Accounts

All users who can log in to the SRC software must be a member of a login class. With login classes, you define the following:

- Access privileges users have when they are logged in to the SRC software
- Commands and statements that users can and cannot specify
- How long a login session can be idle before it times out and the user is logged out.

You can define any number of login classes. You then apply one login class to an individual user account.

