

## Commonly Used Operational Mode Commands

Table 1 on page 1 lists operational commands that you may find useful to monitor system operation. For a complete description of operational commands, see *SRC-PE CLI Command Reference*.

**Table 1: Commonly Used Operational Mode Commands**

Items to Check	Description	Command
CLI	Settings for CLI environment	show cli
Configuration	Current system configuration	show configuration
	Configuration at a specific configuration level	show   display level <number>
Manipulate files	List of files and directories	file list
	Contents of a file	file show
Redirect server	Redirect server usage information	show redirect-server statistics
SRC licenses	Type of license and detailed license information	show sae licenses
System	General system information, including hostname, hardware version, software version, disk usage	show system information
System components	List of installed components and the status of each component	show component

