

Configuring Initialization Scripts

When the SAE establishes a connection with a policy server, it runs an initialization script to customize the setup of the connection.

Use the following configuration statement to configure the initialization script:

```
shared sae configuration driver scripts {  
    pcmm pcmm;  
}
```

To configure initialization scripts for the SAE:

1. From configuration mode, access the configuration statement that configures the initialization scripts.

```
user@host# edit shared sae configuration driver scripts
```

2. Specify the initialization script for a PCMM environment.

```
[edit shared sae configuration driver scripts]  
user@host# set pcmm pcmm
```

The script is run when the connection between a policy server and the SAE is established and again when the connection is dropped. For the JPS, we recommend setting this value to `amlorPublisher`.

