

## Configuring IGMP Conditions (C-Web Interface)

---

To configure IGMP conditions:

1. In the side pane, expand a traffic condition, and select **Igmp Condition**.
2. Click **Create**, enter information as described in the Help text in the main pane, and click **Apply**.

