

Configuring a C-series Controller to Accept NETCONF Connections (C-Web Interface)

To configure the C-series Controller to accept NETCONF connections:

1. Click **Configure**, expand **System > Services**, and then click **NETCONF**.

The NETCONF pane appears.

2. Click **Create**, enter information as described in the Help text in the main pane, and then click **Apply**.

