

Enabling Automatic Discovery of Changes in SAE Configuration Data

To enable automatic discovery of changes in SAE configuration data:

1. Click **Configure**, expand **Shared > SAE**, and then click **LDAP**.

The LDAP pane appears.

2. Click **Create**, enable the Enable Directory Eventing box as described in the Help text in the main pane, and then click **Apply**.

