

## Configuring the SNMP Agent

---

To configure the SNMP agent to control its operation:

1. Configure information supplied by the SNMP agent, including the listening address and system information.

See [Configuring System Information for the SNMP Agent](#) .

2. Configure access control for the SNMP agent, including access for SNMPv3 users, SNMPv1 and SNMPv2 communities (traditional access control), and the view-based access control model (VACM).

See [Configuring Access Control for SNMPv3 Users](#) .

See [Configuring Access Control for Communities](#) .

See [Configuring Access Control for the VACM](#) .

3. Configure active monitoring.

See [Configuring Notification Targets](#) .

