

## Identifying a Profile for Unauthenticated Subscribers (C-Web Interface)

---

The SAE uses an unauthenticated subscriber profile as a transitional profile for subscribers who are not logged in to the SAE. For example, if a subscriber logs out of the SAE using the API method `Subscriber.logout()`, an unauthenticated subscriber session is created. The unauthenticated subscriber profile must exist and can be subscribed to services available for unauthenticated subscribers. The portal implementation determines whether unauthenticated (anonymous) subscribers can access the portal.

To specify an unauthenticated subscriber profile:

1. Click **Configure**, expand **Shared > SAE**, and then click **Driver**.

The Driver pane appears.

2. Click **Create**, specify a subscriber profile for unauthenticated access to the portal as described in the Help text, and then click **Apply**.

