

## Setting Command Completion for the SRC CLI

---

You can enter a Tab after a partially typed command to complete the command. In addition, you can enable and disable the CLI to complete a command by typing a space for:

- Specified users in the user profiles
- A current user session

To disable command completion when entering a space:

- Use the `set cli complete-on-space off` command.

```
user@host> set cli complete-on-space off
```

To re-enable command completion when entering a space:

- Use the `set cli complete-on-space on` command.

```
user@host> set cli complete-on-space on
```

