

## Connecting to a Remote Host Through Telnet

---

To connect to a remote host through Telnet:

- In operational mode, enter the following command.

```
user@host> telnet host <port port >
```

where:

- *host* —Hostname or IP address of the remote host.
- **port** *port* —(Optional) Port number or service name on the remote host.

