

## Exporting a VTA Configuration to a Local File

To export a VTA configuration to a local file:

1. In the VTA Configuration Manager navigation pane, select **Export**.

The Export The Current Configuration page appears.



2. Right-click the word **here**, and then use your browser to save the file.

