

## Viewing JPS CMTS Statistics with the C-Web Interface

**Purpose** View information about recent performance statistics for the policy server-to-CMTS interface.

**Action** Click **JPS > Statistics > CMTS**.

The Statistics/CMTS pane displays statistics for the policy server-to-CMTS interface.

The screenshot displays the Juniper C-Web Interface. At the top, there is a navigation bar with tabs: Monitor (highlighted), Configure, Diagnose, and Manage. To the right of these tabs, it says "Logged in as: admin" and provides links for Refresh, Preferences, About, and Logout. On the left side, there is a vertical menu with various system components: CLI, Component, Date, Disk, Interfaces..., JPS (highlighted), NIC, NTP, Redirect Server, Route..., SAE, Security, and System. The main content area on the right shows the "JPS" section, specifically "Statistics / CMTS". Below this, a table titled "JPS CMTS Interface (PKT-MM-2)" displays the following statistics:

Connections opened	0
Connections closed	0
Sync-Request/SSQ broadcasts	0
Avg sync time (last 10 syncs, ms)	0
Timed out syncs	0

At the bottom of the interface, there is a footer with copyright information: "Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy." and the Juniper logo with the tagline "Juniper Your Net."

**Related Topics** ■ Overview of the JPS

