

Displaying JPS Status

Purpose Display the JPS status.

Action `user@host> show component`

The system responds with a status message.

