

## Reviewing the Information Collected from a JUNOS Routing Platform (C-Web Interface)

---

**Purpose** Review information that the network publisher collects from a JUNOS routing platform.

**Action** To configure the network publisher to use an input file:

- Click **Configure**, expand **Slot**, expand the slot for which you want to configure the network publisher, and then expand **Network Publisher > Routers > Test Mode**.

Or

Click **Configure**, expand **Slot**, expand the slot for which you want to configure the network publisher, and then expand **Network Publisher > Routers > *specific-router* > Test Mode**.

The Test Mode pane appears.

- Select **Enable Output File**.
- Run the network publisher.

See Running the Network Publisher.

- Related Topics**
- Overview of the Network Publisher
  - Troubleshooting Network Publisher Operations

