

Viewing Information About the Directory Blacklist

Purpose View information about the directory blacklist configured on the SAE.

Action 1. Click **Monitor > SAE > Directory Blacklist**.

The Directory Blacklist pane appears.

The screenshot shows the Juniper SAE web interface. The top navigation bar includes 'Monitor', 'Configure', 'Diagnose', and 'Manage'. The user is logged in as 'admin'. The left sidebar lists various configuration categories: ACP, CLI, Component, Date, Disk, Interfaces..., Iptables..., JPS, NIC, NTP, Redirect Server, Route..., SAE (highlighted), Security, and System. The main content area is titled 'SAE Directory Blacklist'. It features a 'Slot' input field with a value of '0'. A tooltip explains: 'Display SAE information for a specified slot. Value: Currently the chassis has only one slot. The valid value is 0. Default: 0'. Below the input field are 'OK' and 'Reset' buttons. The footer contains copyright information for Juniper Networks, Inc. (2007) and the Juniper logo.

2. In the Slot box, enter the number of the slot for which you want to display directory blacklist information.

The Directory Blacklist pane displays the directory blacklist information.

